Highlights:

- 1. The arms of the robot toy can swing back and forth.
- 2. When it works, the robot toy can Lighten and play music.
- 3. The head can swing left and right.
- 4. The legs can walk back and forth.
- 5. The electronic toy has one key to perform automatically including walk, light, play music.
- 6. The robot machine needs 4 *AA batteries, the remote control needs 2 *AA batteries. (not included)

Specifications

• Pack: Window box

robot Size: 15.0X10.0X23.0 CMCarton Size:77.0X46.0X62.0 CM

• QTY / CTN: 24pcs

• G.W / N.W:. 17.5 / 15.5 (KGS)

Package Content


1xRobots

1xRemote Controller













The head can swing left and right













