

## Особенности

I6s оборудует с 2-мегапиксельной HD камерой.

Одним из ключевых для возврата функции позволяет легко найти дорогу домой.

Три контроля скорости, летать так устойчиво и быстро.

4 канала, который может сделать восхождение, спуск, вперед, назад, влево вбок мухе, право вбок летать и прокатки 360 °.

Он имеет 6-осевой гироскоп, который может иметь более стабильный полет и быть легко контролировать.

Доступно для использования в помещении и на открытом воздухе летать.

Легкий вес планера с хорошей прочностью.

## Характеристики

Материал: ABS

Цвет: черный

Пульт дистанционного управления: 2,4 ГГц / 4 канала / режим 2

Гироскоп: Шесть осей

Двигатель: Coreless двигатель

Камера: камера 2.0MP

Функция: вверх / вниз, влево / вправо, вперед / назад, влево полет / полет Вправо, переворачивается & Amp; роллы, компас, камера

Аккумуляторная батарея для Quadcopter: 3.7V 450mAh Li-Po

Время зарядки: около 60 минут

Время работы: 5 минут

Батарея пульта дистанционного управления: 6 \* AA батареи (не включены)

Drone Размер: 13 \* 12 \* см

Вес товара: 40g

## Содержание пакета

1 x [РС Дрон](#)

1 x передатчиков

1 кабель USB

1 x отверток

6 x Propeller

1 x Руководство



**i**  
i Drone




i6s 39g

---

## Extraordinary stability

The i Drone is the most high-end, high-tech, and stable six axis drone. It is also the first of its kind to be built to such a small size that allows you to fly freely indoors.





# A new way to capture the moment and the happiness around us

The power of the camera on the i Drone will not disappoint you!

720P  
2mega  
HD camera



USA Inven Sense



2 mega HD camera



2.4G Flight range:  
about 50 meters



Super light-weight 39G



450mAh high  
capacity battery



Flight time approx.  
6mins



Enhanced version  
# 6 micro motor



Charging time approx.  
50mins



Google

# Remote control user guideline





## NEVER GET LOST

Compass mode fused with the "one button to return" orientation mode will allow you to control the i Drone to fly safely to places even beyond your vision and return with a press of a button.




Compass mode and "one button to return" mode requires user to point the intended direction of flight first before turning on the i Drone.













---

## Standard set specifications





Aerocraft



with LCD transmitter x1



Instructions x1



universal USB charging line x1



Screwdriver x1



Propeller x4