























(Phone Not included)

MOBILE PHONE MOUNTING BRACKET

POWER INDICATOR

FLIP KEY

CAMERA CONTROL
CLICK ON THE PHOTO/
2 SECONDS LONG VIDEO,
THEN PRESS THE STOP

FORWARD/ BACKWARD
TRIMMING

LOW MEDIUM AND HIGH
SPEED CONVERSION KEY

FORWARD AND BACK LEFT
AND RIGHT DIRECTION
JOY STICK

ACCELERATOR AND
DIRECTION JOY STICK

LEFT RIGHT SIDEWAYS
TRIMMING

LEFT/RIGHT TURN
TRIMMING

HEADLESS MODE

POWER SWITCH

ONE PRESS AUTOMATIC
RETURN

1.5V x6 Required with 6X1.5V "AA" batteries(Not included)