

□□□□

- * 20□□ 1 □□□ □□ □□ □□□
- * □□ □□, □□□□□ □□

□□□

- * □□ : ABS
- * □□ : □□ / □□
- * □□ : 1□ 20□
- * □□ : 41 × 14.5 × 18 CM
- * □□ : 4 □□
- * □□ □□ □□□ : 2.4
- * □□ : □□□ / □□ / □□□□ / □□□□
- * □ □□□ □ : NI-CD 4.8V 500MAh □□□ □□□ □ □□
- □□ * □□□□ : 4 x 1.5V AA □□□ (□□□□ □□)
- * □□ □□ □□ : □ 30-40m
- * □□ □□ : □ 90 □
- * □□ □□ : □ 20□
- * □□ : □□ 25 / H
- * □□□□ □□ : 6 □ □□

□□□ □□

- 1 □ □
- 1 X □□□□
- 1 □ NI-CD 4.8V 500MAh □□□ □□□
- 1 □ □□□









