

## □□□□

- \* 3 □□
- \* □□□ 40 CM
- \* □□□ : 27,35,40,49 MHZ

## □□□

- \* □□: ABS
- \* □□ : □□ / □□
- \* □□ : 39.5 × 19.5 × 8 CM
- \* □□ : 3
- \* □□ : □□ / □□□, □□□ / □□ □□
- □□ \* □□□ : NI-CD 7.2V700mAh □□□ □
- \* □□□□ : 3x1.5V "AA" ( □□□□)
- 7.2V / 250MAH : □□ \* □□□□
- \* □□ □□ : □ 4□□
- \* □□ □□ : □ 10 ~ 12 (□)
- \* □□ □□ : □ 50 ~ 70 M
- \* □□ : 10 ~ 15 KM / H
- \* □□□□ □□ : 8 □ □□

## □□□ □□

- 1 X RC □□
- 1 X □□□
- 1 X □□ □□
- 1 X 7.2V □□□
- 2 X □□□□
- 1 × □□□ / □□ □□□











