

□□□□

- * □□ □□ □□ 4 □□ □□.
- * □□ □□ 4 □ □□□□ □□.
- * □ / □ / □ / □ / □□□ □□ / □□□ / □ □□.
- * □□ □□ □□.
- * □□ □□□□□ LED □.

□□□

- * □□ □□ : CX - 10
- * □□ □□ : □□ □, □□ □□□
- * □□ □□ : 4 * 4 * 2.2 CM
- * □□ □□ : 7.5 * 7.5 * 15cm
- * □□ □□ : 42 * 33 * 52cm
- * □□ □□ : 60 □ / □□
- * □□ □□ : 4 □□ □□□ □□□□ 6 □
- * □□ □□ : □□ / □□ / □□□□ / □□
- * □□ □□ □□ : 2.4 G
- * □□ □□ □□ : 20m
- * □□ □□ : □□□
- * □□ □□ : 1 □
- * □□ □□□ : 3.7 V 100 MAH □□ □□□
- * □□ □□ : 2 * AAA (□□□□ □□)
- * □□ □□ □□□□□ □□, □□□□ □□ □□
- * □□ □□ I : □□□ □□□□□ 6 □ 4CH : □ / □□, □□ / □□□, □□□ / □□, □□ □□, □□ □ □□, □ □□ □□, □□ □□ □□□ □□ □□□, 3 □□□ □ □□.

□□□ □□

- 1 * □□ □□ □□
- 1 * 4CH □□ □□□ □□□□ (□□ 2)
- 4 * □□ □□□□
- 1 * USB □□□□ □□□
- 1 * □□ □□□









