#### **Highlights**

- 1) Operation System: Drive it with your iPad®, iPhone® or iPod touch® device, or with Android™ smart phones and tablets
- 2) See in the dark using Rover's built-in night vision
- 3) Stream and record live video and stills
- 4) Upload videos and stills to Facebook, Youtube and Twitter sites by smart phones and tables
- 5) Control the angle of the video camera remotely
- 6) Its wide-angle lens captures more of its surroundings
- 7) Wifi: b/g
- 8) Built-in LED Indicator (Indicate to the charging state & movement state)
- 9) Wireless range up to 100 ft. unobstructed: 50 ft. around walls and into other rooms
- 10) Free App from the iTunes® App Store and Google Play
- 11) Indoor Battery: 3.7V 3000Mah Li-poly
- 12) Playing Time: Stand by 240 minutes (Connected), Operation 90 minutes (Take photos, video & Runing)

### **Specifications**

Car Size: 18x18x11cm

Package Dimension: 32.5x25x13.5cm

Packing:6pcs

Meas:52.5x34.5x43.5cm

Car Weight: 700g

Battery: 3.7V 3000mAh Li-Poly

Control Range: 10-30M

Suitable for all iPhone, iPad and iPod Touch models

Up to 8 hours of standby time.







# CLOUD ROVER










# Name of the funtion key



#### CHARGING



# **△** CAUTION:

Do not remove the indoor battery out of the Cloud Rover™ Vehicle.

#### Notes:

Each Cloud Rover™ vehicle has an unique SSID address ( stick on the underside of each vehicle). If there are multiple vehicle's being used, the individual SSID address will appear as Wi-Fi connection on your device, select your vehicle's SSID address.

## **HOW TO CONNECT THE WI-FI**

- Please check up the SSID number on the bottom of the vehicle. Move the power switch on the vehicle to "ON" position. The power will illuminate, Wait approximately 60 seconds and the signal light will start to blink slowly.
- On your iOS, Android and PC system device, go to settings and trun on the Wi-Fi. The SSID address of your vehicle will appears as an available connection.
- Select the vehicle to confirm the connection. Ensure there is a check mark to the left of the SSID address and the Wi-Fi connection logo appears at the top of your device's screen.

- Exit out of setting and open the "Cloud Rover™".
  - 1. Turn the vehcile power switch on "OFF" or "ON" Position.
- 2. The tail light will be red flashing when charging.
- When the charging completely finished, All the tail flash light will be light up in red.

Remark: The Charging time will be shorted in half when the power switch is on "OFF" state.

- 5. The signal light will blink faster now.
- When your device screen shows the view from the vehicle's live-stream video camera. Your are ready to start exploring.



Charging And Running Led Indicator



# PACK LIST

Go to Official websit www.icloudrover.com

Click, download & install the software Free!

Turn on the Vehicle

Go to setting and turn on smart phone wifi

Select the SSID address of your vehcile

# **PACK LIST**

#### Contents:

- 1 PC x Cloud Rover™ vehicle
- 1 PC x Antenna
- 1 PC x AC Charger
- 1 PC x Instruction Manual

#### **↑** WARNING:

- Please Charge the Cloud Rover<sup>™</sup> about 2.5 hours before playing. All the tail flash light will be light up in red after full charged.
- 2. Smart phone power less than 40%, Signal will become weak.