#### Особенности

- 1) Операционная система: Поездка его с iPad®, iPhone® или устройства Ipod Touch®, или с Android <sup>™</sup> смартфонов и планшетов
- 2) видеть в темноте с помощью встроенного в ночное видение Ровера
- 3) поток и записывать видео и кадры
- 4) Загрузить видео и фотографии на Facebook, Youtube и Twitter сайтов по смартфонов и таблиц
- 5) Удаленное управление угол видеокамеры
- 6) Его широкоугольный объектив захватывает больше его окрестностях
- 7) Wi-Fi: 6 / Γ
- 8) Встроенный светодиодный индикатор (Укажите к зарядному государственной и усилитель; движения состоянии)
- 9) Беспроводная диапазоне до 100 футов препятствий:. 50 футов вокруг стен и в другие комнаты.
- 10) бесплатное приложение из Play iTunes® App Store и Google
- 11) Крытый батареи: 3.7V 3000mAh литий-поли
- 12) Время воспроизведения: Стенд 240 минут (Connected), Операция 90 минут (Возьмите фотографии, видео & Amp; Runing)

#### Характеристики

Автомобиль Размер: 18x18x11cm Размер коробки: 32.5x25x13.5cm

Упаковка: 6шт

Изм: 52.5x34.5x43.5cm Автомобиль Вес: 700г

Батарея: 3.7V 3000mAh Li-Poly Диапазон управления: 10-30м

Подходит для всех моделей iPhone, IPad и IPod Touch

До 8 часов в режиме ожидания.







# CLOUD ROVER










# Name of the funtion key



#### CHARGING



## **△** CAUTION:

Do not remove the indoor battery out of the Cloud Rover™ Vehicle.

#### Notes:

Each Cloud Rover™ vehicle has an unique SSID address ( stick on the underside of each vehicle). If there are multiple vehicle's being used, the individual SSID address will appear as Wi-Fi connection on your device, select your vehicle's SSID address.

### **HOW TO CONNECT THE WI-FI**

- Please check up the SSID number on the bottom of the vehicle. Move the power switch on the vehicle to "ON" position. The power will illuminate, Wait approximately 60 seconds and the signal light will start to blink slowly.
- On your iOS, Android and PC system device, go to settings and trun on the Wi-Fi. The SSID address of your vehicle will appears as an available connection.
- Select the vehicle to confirm the connection. Ensure there is a check mark to the left of the SSID address and the Wi-Fi connection logo appears at the top of your device's screen.

- Exit out of setting and open the "Cloud Rover™".
  - 1. Turn the vehcile power switch on "OFF" or "ON" Position.
- 2. The tail light will be red flashing when charging.
- When the charging completely finished, All the tail flash light will be light up in red.

Remark: The Charging time will be shorted in half when the power switch is on "OFF" state.

- 5. The signal light will blink faster now.
- When your device screen shows the view from the vehicle's live-stream video camera. Your are ready to start exploring.



Charging And Running Led Indicator



# PACK LIST

Go to Official websit www.icloudrover.com

Click, download & install the software Free!

Turn on the Vehicle

Go to setting and turn on smart phone wifi

Select the SSID address of your vehcile

# **PACK LIST**

#### Contents:

- 1 PC x Cloud Rover™ vehicle
- 1 PC x Antenna
- 1 PC x AC Charger
- 1 PC x Instruction Manual

#### **↑** WARNING:

- Please Charge the Cloud Rover<sup>™</sup> about 2.5 hours before playing. All the tail flash light will be light up in red after full charged.
- 2. Smart phone power less than 40%, Signal will become weak.