Mette in evidenza

1) Sistema di esercizio: guidare con il tuo iPad®, iPhone® o iPod touch® dispositivo, o con Android ™ smartphone e tablet
2) Si veda al buio utilizzando built-in visione notturna di Rover
3) Stream e registrare in diretta video e foto
4) Carica video e fotografie a siti di Facebook, Youtube e Twitter per smartphone e tabelle
5) Controllare l'angolo della telecamera in remoto
6) Il suo obiettivo grandangolare cattura più dei suoi dintorni
7) Wifi: b / g
8) incorporato Indicatore LED (indicare lo stato di carica & amp; stato di movimento)
9) portata wireless fino a 100 piedi senza ostacoli:. 50 ft intorno alle mura e in altri locali.
10) Free App da Play iTunes App Store e Google
11) La batteria interna: 3.7V 3000mAh Li-poli
12) Tempo di gioco: Stand by 240 minuti (Collegato), Operation 90 minuti (Scatta foto, video & amp; Predellino)

Specifiche

Auto Dimensione: 18x18x11cm
Dimensione Pacchetto: 32.5x25x13.5cm
Imballaggio: 6pcs
Meas: 52.5x34.5x43.5cm
Auto Peso: 700g
Batteria: 3.7V 3000mAh Li-Poly
Gamma di controllo: 10-30m
Adatto a tutti i modelli di iPhone, iPad e iPod
Fino a 8 ore in standby.

Cloudrover

CLOUD ROVER

CLOUD ROVER™

Operation step

1. go App store

2. search"i-spy toys" download & install - free!

3. Turn on the product

4. go to setting and turn on wi-fi

5. select the SSID address of your tank

6. go to the control interface

7. start game



Name of the funtion key



CHARGING

⚠ CAUTION:

Do not remove the indoor battery out of the Cloud Rover™ Vehicle.

Notes:

Each Cloud Rover™ vehicle has an unique SSID address (stick on the underside of each vehicle). If there are multiple vehicle's being used, the individual SSID address will appear as Wi-Fi connection on your device, select your vehicle's SSID address.

HOW TO CONNECT THE WI-FI

1. Please check up the SSID number on the bottom of the vehicle. Move the power switch on the vehicle to "ON" position. The power will illuminate, Wait approximately 60 seconds and the signal light will start to blink slowly.
2. On your iOS, Android and PC system device, go to settings and trun on the Wi-Fi. The SSID address of your vehicle will appears as an available connection.
3. Select the vehicle to confirm the connection. Ensure there is a check mark to the left of the SSID address and the Wi-Fi connection logo appears at the top of your device's screen.
4. Exit out of setting and open the "Cloud Rover™".
   1. Turn the vehcile power switch on "OFF" or "ON" Position.
   2. The tail light will be red flashing when charging.
   3. When the charging completely finished, All the tail flash light will be light up in red.

   Remark: The Charging time will be shorted in half when the power switch is on "OFF" state.
5. The signal light will blink faster now.
6. When your device screen shows the view from the vehicle's live-stream video camera. Your are ready to start exploring.

Charging And Running Led Indicator

PACK LIST

Go to Official websit www.icloudrover.com
↓
Click, download & install the software Free !
↓
Turn on the Vehicle
↓
Go to setting and turn on smart phone wifi
↓
Select the SSID address of your vehcile
↓
Go to the control interface ⟶ Star your Games !

PACK LIST

Contents:
1 PC x Cloud Rover™ vehicle
1 PC x Antenna
1 PC x AC Charger
1 PC x Instruction Manual

⚠ WARNING:

1. Please Charge the Cloud Rover™ about 2.5 hours before playing. All the tail flash light will be light up in red after full charged.
2. Smart phone power less than 40%, Signal will become weak.