□□□□□
1.Replaceable□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□
3□□□□□2.6□□□□□□□□□□
3.With 2.0MP□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□
4.6□□□□□□□□□□□□□□□□□□□□□□□□□
5.It□□
6.360□□□□□□□□□□□□□□□□□□□□□□□□□□□□□
7.Colorful□LED□□□□
□□□□□□□□□□□□□□□8.Suitable□
9.Mini□□□□□□□□□□□□□□□□□□□□□□□ MINI□□□□□□□□□□□□□□□□□□□
□□□□□□□□□□
10.Headless□□□□□□□□□□□□□□□□□□□□□□□□□□□□
11.MODE1&□038; MODE2 1□□□□□□□
12.One□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□
□□□□□□□□□□□□□□□□13.charge□
14.Transmitter□□
□□□

□□□□□□□□□□□□□□□□□
□□□□30M
□□□□2.0MP
□□□□□□□□□□□□□□□□□
□□□□□60□
□□□□□5mins□□□□
□□□□□□2.4GHz□
□□□□□□□□□□3.7V 220mAh□Li-Po□□□□□
□□□□□□□4×AA□□□□□□□□□□□□
□□□□□3.7V
□□□□□□□□□□□□8 * 7.1 * 2.45□□□□□□□

□□□HD□□□□□□□/□□□□360□□□□□□□□□□MODE1&□038; MODE2□□□□□□□/□□□□□□□□□□□□□□□□□□□□□/□□□□□□□□□□□□
□□□□□□□
□□□□□□□□
1× □□□□□□□□
1×□□□□□□□
1×2.0MP□□□
1×USB□□□
1×3.7V 220mAh□Li-Po□□□□□
6×□□□□
2×□□□□□□□
1×□□□□□
1×□□□□□
1×2G□□□□□□
1×□□□□□□□

FQ777®

14+ AGES

SPIDER DRONE HEXACOPTER 126C

With HD Camera

HD CAM Equipment | HEADLESS Mode | 6AXIS Stabilization System | LIGHT Lights shine to remind low power | 360° Unlimited Eversion | MODE switch | ONE KEY returm

FQ777®

SPIDER DRONE HEXACOPTER 126C

SPIDER DRONE HEXACOPTER 126C

With HD Camera

FQ777®

BLACK

SPIDER DRONE HEXACOPTER 126C

With HD Camera

FQ777®

SPIDER DRONE HEXACOPTER 126C

With HD Camera

FQ777®

RED

FQ777®

BLACK

WHITE



RED

SPIDER
DRONE HEXACOPTER 126C

SPIDER DRONE HEXACOPTER 126C

With HD Camera

FQ777®

BLACK

SPIDER DRONE HEXACOPTER 126C

With HD Camera

FQ777®

WHITE

SPIDER DRONE HEXACOPTER 126C

With HD Camera

FQ777®

RED

SPIDER DRONE HEXACOPTER 126C

With HD Camera

FQ777®

HD CAMERA ANGLE,
LET'S SHOW VISUAL EFFECT
BROADER AND CLEARER!

SPIDER DRONE HEXACOPTER 126C

With HD Camera

FQ777®

BACK

SPIDER DRONE HEXACOPTER 126C

With HD Camera

FQ777®

HEXACOPTER SIZE:108X98X25mm

BOX SIZE:188X117X52mm

SPIDER DRONE HEXACOPTER 126C

With HD Camera

FQ777®

MODE 1



MODE 2



SPIDER DRONE HEXACOPTER 126C

With HD Camera

FQ777®

The RC Transmitter Default mode 2

MODE 1 / MODE 2 SWITCH

YOU CAN PRESS DOWN THE ACCELERATOR KEY
AT THE SAME TIME OPER THE BACK OF THE TRANSMITTER
MODE 1/2 SWITCH INTO THE MODE 1

SPIDER DRONE HEXACOPTER 126C

With HD Camera

FQ777®

Headless mode calibration

Gyroscope calibration