亮点

1）操作系统：与你的iPad®，iPhone®的或iPodTOUCH®设备，或者与Android™智能手机和平板电脑推动IT
2）请参见使用罗孚的内置夜视黑暗
3）流和记录现场视频和剧照
4）通过智能手机和表格上传视频和照片至Facebook，YouTube和Twitter的网站
5）远程地控制摄像机的角度
6）其广角镜头捕获更多的它的周围
7）无线：B / G
8）内置LED指示灯（指示的充电状态和放大器;运动状态）
9）无线范围达100英尺通畅：50英尺周围的墙壁，进入其他房间。
10）免费应用程序从iTunes®应用商店和谷歌播放
11）室内电池：3.7V 3000mAh的锂聚合物
12）播放时间：240分钟（连接），运行90分钟支架（以照片，视频和放大器;乳宁）

技术指标

车尺寸：18x18x11cm
包装尺寸：32.5x25x13.5cm
包装规格：6件
尺寸：52.5x34.5x43.5cm
车重：700克
电池：3.7V 3000mAh的锂聚合物
控制范围：10-30M
适用于所有的iPhone，iPad和iPod touch机型
长达8小时的待机时间。

Cloudrover

CLOUD ROVER

CLOUD ROVER™

Operation step

1. go App store

2. search"i-spy toys" download & install - free!

3. Turn on the product

4. go to setting and turn on wi-fi

5. select the SSID address of your tank

6. go to the control interface

7. start game



Name of the funtion key



CHARGING

⚠ CAUTION:

Do not remove the indoor battery out of the Cloud Rover™ Vehicle.

Notes:

Each Cloud Rover™ vehicle has an unique SSID address (stick on the underside of each vehicle). If there are multiple vehicle's being used, the individual SSID address will appear as Wi-Fi connection on your device, select your vehicle's SSID address.

HOW TO CONNECT THE WI-FI

1. Please check up the SSID number on the bottom of the vehicle. Move the power switch on the vehicle to "ON" position. The power will illuminate, Wait approximately 60 seconds and the signal light will start to blink slowly.
2. On your iOS, Android and PC system device, go to settings and trun on the Wi-Fi. The SSID address of your vehicle will appears as an available connection.
3. Select the vehicle to confirm the connection. Ensure there is a check mark to the left of the SSID address and the Wi-Fi connection logo appears at the top of your device's screen.
4. Exit out of setting and open the "Cloud Rover™".
   1. Turn the vehcile power switch on "OFF" or "ON" Position.
   2. The tail light will be red flashing when charging.
   3. When the charging completely finished, All the tail flash light will be light up in red.

   Remark: The Charging time will be shorted in half when the power switch is on "OFF" state.
5. The signal light will blink faster now.
6. When your device screen shows the view from the vehicle's live-stream video camera. Your are ready to start exploring.

Charging And Running Led Indicator

PACK LIST

Go to Official websit www.icloudrover.com
↓
Click, download & install the software Free !
↓
Turn on the Vehicle
↓
Go to setting and turn on smart phone wifi
↓
Select the SSID address of your vehcile
↓
Go to the control interface ⟶ Star your Games !

PACK LIST

Contents:
1 PC x Cloud Rover™ vehicle
1 PC x Antenna
1 PC x AC Charger
1 PC x Instruction Manual

⚠ WARNING:

1. Please Charge the Cloud Rover™ about 2.5 hours before playing. All the tail flash light will be light up in red after full charged.
2. Smart phone power less than 40%, Signal will become weak.