## Mette in risalto

I6S equipaggia con fotocamera da 2 megapixel HD.
Una chiave per la funzione restituire lo rende facilmente trovare la strada di casa.
Regolazione a tre velocità, volare così costante e veloce.
4 canali che possono fare salire, scendere, avanti, indietro, a sinistra volare lateralmente, mosca laterale destra e di laminazione a 360 °.
Ha giroscopio a 6 assi che possono avere volo più stabile ed essere facile da controllare.
Disponibile per interni ed esterni in volo.
struttura del velivolo leggero con una bella durata.

## specifiche tecniche

Materiale: ABS
Colore: Nero
Telecomando: 2,4 GHz / 4 canali / modalità 2
Giroscopio: sei assi
Motore: Motore Coreless
Camera: fotocamera 2.0MP
Funzione: Up / Down, sinistra / destra, avanti / indietro, volo a sinistra / volo verso destra, lancia & rotoli, bussola, macchina fotografica
Batteria per quadcopter: 3.7V 450mAh Li-Po
Tempo di ricarica: circa 60 minuti
Orario di lavoro: 5 minuti
Batteria di telecomando: batteria a 6 * AA (non incluse)
Drone Dimensioni: 13 * 12 * cm
Peso dell'articolo: 40g

## Contenuto del pacco

1 x RC Drone
1 x Trasmettitore
1 x cavo USB
1 x Cacciavite
6 x Elica
1 x Manuale

# i Drone

i6s 39g

## Extraordinary stability

The i Drone is the most high-end, high-tech, and stable six axis drone. It is also the first of its kind to be built to such a small size that allows you to fly freely indoors.


8.5cm
4cm
13cm


A new way to capture the moment
and the happiness around us
The power of the camera on the i Drone will not disappoint you!
720P
2mega
HD camera
USA Inven Sense
2 mega HD camera
2.4G Flight range:
about 50 meters
Super light-weight 39G
3. 7V
450mAh high
capacity battery
Flight time approx.
6mins
Enhanced version
ϕ6 micro motor
Charging time approx.
50mins
Google

# Remote control user guideline

# NEVER GET LOST

Compass mode fused with the " one button to return " orientation mode will allow you to control the i Drone to fly safely to places even beyond your vision and return with a press of a button.

Compass mode and " one button to return " mode requires user to point the intended direction of flight first before turning on the i Drone.





# Standard set specifications

Aerocraft

with LCD transmitter x1

Instructions x1

universal USB charging line x1

Screwdriver x1

Propeller x4