Highlights

2.4GHz control system: It ensures the strongest anti-interference performance and strong signal.
6 axis Gyro: For the flight more stable and stronger in the wind.
Real time transmission WIFI: With 1.5MP camera, share videos and pictures to the LCD anytime anywhere.
4D subversion: Four directions independent, cool and exquisite flight action.
Headless mode: automatically locks in the direction of take-off, no matter where it is.
A key to return: You can find his way home easily.
Colorful LED light: Suitable to fly in the dark of night.
LCD Transmitter: Adopts delicate design, built-in 2.4G antenna special.
High-performance 7.4V 500mAh lipo: Double internal protection panels, intelligent current automatic identification system charging.

Specifications

* Material: ABS
* Color: red / white / black
Quadcopter * Size: 36 * 36 * 13cm
* Channels: 4 channels
* Function: up / down, forward / backward, left / right, flight To the left / right flight, flips & amp; amp; sandwiches, headless mode, Auto-return FPV REAL TIME
* Gyroscope: Yes
* Remote control frequency: 2.4 GHz
* Remote control range: Approximately 120metres
* Power Battery: 7.4V 400mAh Li-ion Battery
* Battery of controller: 2 x 1.5V AA batteries (not included)
* Charging time: about 60-90minutes
* Working time: About 8 minutes
* Room PIEXL: 1.5MP
* Age appropriate: Over 14 Years

Package Contents

1 x RC Quadcopter,
1 x Transmitter,
1 x USB Cable,
4 x Lama,
4 x Protection Frame,
1 x Screwdriver,
4 x Screw,
1 x 7.4V 500mAh Li-Po Battery,
1 x 1.5MP camera,
1 x card reader,
1 x SD Memory 4G,
1 x mobile clips

T-SERIES

2.4GHZ AIRCRAFT WITH ONBOARD CAMERA

QUADCOPTER

- ➤ 360°4DEVERSION
- ➤ AUTO-RETURN
- ➤ HD-CAMERA
- ➤ SIX AXIS GYROSCOPE

2.4GHz
RADIO SYSTEM

360°
4D
EVERSION

BLADE

PROTECTION COVER

MOTOR

MAIN CASE

CAMERA

LANDING GEAR

PRODUCT DETAILS

1 UNIQUE APPEARANCE DESIGN

2 TOUGH BLADE

3 SEPARATE MOTOR

4 FLASH LIGHT

5 COOLING HOLE

6 PROTECTION COVER

7 HD CAMERA

8 FLEXIBLE LANDING GEAR

Install the protective frame onto the small holes below the blade

Fix it with screws

Mount the landing gear onto the bottom of the aircraft

Fix it with screws again

Fit the camera into the battery cover slot

Connect the power wire

REMOTE CONTROL STRUCTURE

Phone clip

Eversion/shooting mode (long press)
Auto-return (short press)

Headless/common mode (short press)
Initialization (long press)

SJ-SERIES

运行状态

LED color display

Throttle control rod

Rotary tuning (right/left)

Direction control rod

Speed regulation: Up: accelerate
Down: decelerate

Power switch

Front and back /left and right
Side flight tuning